



Nintendo Switch Connection Guide

- Make sure your Nintendo Switch is registered at mydevices.uww.edu.
- Select "System Settings" from the HOME Menu.



- Select "Internet," and then "Internet Settings."



- The Nintendo Switch will automatically search for near-by Wi-Fi signals.
- Scroll to the bottom of the networks listed under "Networks Found," & select "Manual Setup."



- Select from the following options, and enter the appropriate network information:



The screenshot shows a network configuration interface for a device named 'Network1'. It features several input fields and options:

- Network Name:** A text field containing 'Network1'.
- SSID:** A text field containing 'MySSID', which is highlighted with a red border.
- Security:** A dropdown menu currently set to 'None'.
- Enter Password:** A text field for entering a wireless password.

- **Connect to a Hidden Network (UWWPlay is a Hidden Network)**
- Select "On" to allow the Nintendo Switch console to connect to hidden networks (networks that do not broadcast their SSID), or select "Off" to not allow this.
- Select "Connect to this Network" to test the saved connection, or select "Back" to return to the Internet settings.
 - **Network Name** - Enter the nickname you would like to give this network connection within the Internet settings.
 - **SSID** - Enter the SSID (broadcast name) of the wireless router you are connecting to. **(You will be using UWWPlay as your SSID Network) Remember this is case sensitive.**
 - **Security** - Select the router's security type and enter the router's wireless password.